



**higher education
& training**

Department:
Higher Education and Training
REPUBLIC OF SOUTH AFRICA

MARKING GUIDELINE

NATIONAL CERTIFICATE

INDUSTRIAL INSTRUMENTS N5

17 April 2020

This marking guideline consists of 6 pages.


SECTION A: FLOW MEASUREMENTS**QUESTION 1**

- 1.1
- The large pipe carries a greater volumetric rate of water flow than the small pipe.✓
 - Since the vortex-shedding frequency is proportional to the fluid velocity, the flow velocities in both cases must be the same (given identical bluff body geometries).✓✓
 - However, since the larger pipe has a greater cross-sectional area, an identical velocity equates to a greater volume rate of water moving past the bluff body and sensor.✓✓✓ (6)
- 1.2
- Primary device or measuring unit (2)
 - Secondary device or recording unit
- 1.3
- Gravity (2)
 - Pump
- [10]

QUESTION 2

- 2.1
- $$Q = V_1 A_1 = V_2 A_2 ✓✓$$
- $$2,21 \left(\frac{\pi D^2}{4} \right) = V_2 \left(\frac{\pi D^2}{4} \right) ✓$$
- $$2,21 \left(\frac{\pi (0,09)^2}{4} \right) = V_2 \left(\frac{\pi (0,06)^2}{4} \right) ✓$$
- $$0,0141 = 2,827 \times 10^{-3} V_2 ✓$$
- $$V_2 = 4,988 \text{ m/s} ✓$$
- (6)

- 2.2 2.2.1



(6)

2.2.2 Advantages:


- No moving parts
- Low-pressure losses
- High accuracy

Disadvantages:

- Expensive
- In-mounting requirement
- Not accurate in slurry application

(3 + 3)

(6)

2.2.3

(6)

[24]



TOTAL SECTION A:**34****SECTION B: DENSITY, HUMIDITY AND VISCOSITY****QUESTION 3**

- 3.1
- In the displacement meter liquid flows continuously through the displacer chamber.
 - An upward force acts on the balance beam because of the volume of liquid displaced by the float.
 - A pneumatic system balances this upward force and transmits a signal proportional to the density of the liquid.
 - Liquids with specific gravities of 0,5 and higher can be measured with this equipment as long as suitable materials are used to prevent damage from corrosion.
 - If the temperature of the flowing liquid changes, a thermostat heater may be used to hold it constant.

(5)

- 3.2 Newtonian fluids: When fluids are deformed by strain the ratio between shear rate and shear stress will be a constant value.✓✓

Non-Newtonian fluids: When fluids are deformed by strain the ratio between shear rate and shear stress will not be a constant value.✓✓




(3 + 3)

(6)

- 3.3
- The instrument should not be mounted near doors or other openings where it will be exposed to artificial drafts.✓ Flush mounting on the panel should be avoided✓ because the atmosphere in the back of the panel is motionless.✓
 - The hair element can be mounted on top or on the back of the instrument case depending on the installation.✓
 - The element can also be mounted on an extension in the back of the instrument✓ so that the sensing portion is in the room or compartment where relative humidity is to be measured while the readout device is surface mounted on the wall outside.✓✓
 - Recorders are generally available as two-pen instruments with the second pen recording temperature.✓

(8)

3.4 3.4.1




(6)

- 3.4.2 Reference conductivity-cell sampling which is a solution of typical composition✓ and subject the same temperature as the measuring cell.✓ Bring a thermistor in contact with the process fluid and resistor network.✓

(3)
[28]**TOTAL SECTION B:****28**

SECTION C: pH MEASUREMENT**QUESTION 4**

- 4.1 A screened glass electrode can be used✓ and the electrode assembly✓ must be located at a point where the residual field is smallest.✓ (3)
- 4.2 The main purpose is to complete the electrical circuit with the glass-membrane electrode.✓ It must provide a stable potential that is relatively invariable,✓ despite changes in either the chemical composition or physical properties of the process stream.✓ (3)
- 4.3 Hydroxyl ions (2)
- 4.4



For a glass-membrane electrode to function, both surfaces of the membrane must be hydrated.✓ Hydration occurs by absorption of water by the membrane interface in contact with the solution.✓ There is also an exchange of univalent cations of the glass for hydrogen ions from the solution.✓ At both surfaces of the membrane there will be a boundary potential that will be a function of the hydronium ion activity in the solution at the interface.✓ Because the hydronium ion activity for the internal filling solution is constant,✓ the potential will be a function of the hydronium ion activity of the external solution.✓

(4 for diagram + 6 for discussion) (10)
[18]

TOTAL SECTION C: 18

SECTION D: AUTOMATIC CONTROL**QUESTION 5**

- 5.1
- All four bellows will have the same pressure.
 - The motion pin will be on its true centreline.
 - There will be no control actions generated.
- (3)
- 5.2
- The output will increase by 10 kPa if the gain is direct.
 - Should the gain be indirect the output will decrease by 10 kPa.
 - This would be due to the pressure increasing in the process bellows while the pressures in the other bellows stay constant.
 - The motion pin will move off its centreline causing the flapper to move either towards or away from the nozzle.
 - This should cause the nozzle feedback pressure to either increase or decrease thus causing the output to change accordingly.
- (5)
- 5.3 $100\% P_b = 100/\text{gain}$ (1)
- 5.4 By swivelling the gain adjustment dial directly to reverse (1)
- 5.5
- When the integral action is marked in repeats per minute it indicates that the integral will repeat per minute✓
 - When marked in minutes per repeat it indicates the time to repeat the proportional band✓✓
- (3)
- 5.6
- The derivative action time taken for proportional action to repeat the derivative action for a ramp change✓
 - Most controllers do not produce the true theoretical output due to interactions between the control actions✓ and are therefore called interactions controllers✓
- (3)
- 5.7 **Advantages of a live zero-based signal:**
- Difference between power on and power off
 - See movement from zero in both directions
 - Two-wire system (no high voltage in hazardous area)

Advantage of a zero-based signal controller:

- Mathematical functions are easy, as they do not have to be biased
- (4)
[20]

TOTAL SECTION D: 20
GRAND TOTAL: 100