



**higher education  
& training**

Department:  
Higher Education and Training  
**REPUBLIC OF SOUTH AFRICA**

# **MARKING GUIDELINE**

## **NATIONAL CERTIFICATE INDUSTRIAL INSTRUMENTS N6**

**31 March 2020**

**This marking guideline consists of 7 pages.**

**SECTION A****QUESTION 1**

- 1.1 Paramagnetic
- 1.2 Cascade
- 1.3 Division
- 1.4 Continuous spectrum
- 1.5 Two-element

(5 × 1) **[5]**

**QUESTION 2**

- 2.1 Valve characteristic
- 2.2 Flashing
- 2.3 Spectrum
- 2.4 Continuous spectrum
- 2.5 Class III

(5 × 1) **[5]**

**QUESTION 3**


- 3.1 The National Electrical Code defines intrinsically safe equipment and wiring as incapable of realising sufficient electrical or thermal energy✓ under normal or abnormal conditions✓ to cause ignition of specific hazardous atmosphere mixtures.✓ (3)
- 3.2 A process of separating a mixture of two or more substances into their individual components✓ by heating the mixture until the more volatile component passes into the vapour phase✓ and then cooling the vapour to recover such component in liquid form by condensation.✓ (3)
- 3.3
  - An analyser is a device that examines in detail the structure of the given data and tries to find patterns and relationships between parts of the data.
  - An analyser can also be an instrument or device which conducts chemical analysis (or similar analysis) on samples or sample streams. (Any 1 × 2) (2)
- 3.4 Boilers are devices that are used to heat water for the generation of steam and hot water✓ in industrial processing plants where steam demands vary according to the requirements.✓ (2)

**[10]**

**TOTAL SECTION A: 20**

**SECTION B****QUESTION 4**

4.1 4.1.1



(9)

- 4.1.2 In a high-vacuum Coolidge-type tube, electrons are emitted from a heated tungsten filament and accelerated by a high voltage to an anode (target). The process emits the X-rays when the electrons strike the target, i.e. X-rays are emitted by atoms, which are bombarded with energetic electrons due to:

- Deceleration of high-speed electrons as they pass through matter, and/or
- Ionisation of individual atoms that abruptly stop the electrons

(4)

4.2 4.2.1 Mass spectrometer analyser

(2)

- 4.2.2
- A – Sample inlet system
  - B – Electron beam
  - C – Ion source (accelerating and focussing slits)
  - D – Filament
  - E – Analyser
  - F – Pumping system
  - G – Resolving slits
  - H – Ion collector
  - I – Amplifying system
  - J – Recording or data processing

(10)  
[25]

**QUESTION 5**

5.1 5.1.1

$$C_v = 1,16 Q \sqrt{\frac{Gf}{\Delta P}}$$

$$75 = 1,16 \times Q \times \sqrt{\frac{1}{1,5}} \checkmark \checkmark$$

$$= 79,18 \text{ m}^3/\text{h} \checkmark$$

5.1.2

$$\text{Rangeability} = \frac{\text{max flow}}{\text{min flow}}$$

$$46 = \frac{79,18}{\text{min flow}} \checkmark \checkmark$$

$$\text{Min flow} = 1,721 \text{ m}^3/\text{h} \checkmark$$

5.1.3


$$\text{Turndown} = \frac{\text{normal operating flow}}{\text{min flow}}$$

$$42 = \frac{\text{normal operating flow}}{1,721} \checkmark \checkmark$$

$$\text{Normal operating flow} = 72,282 \text{ m}^3/\text{h} \checkmark$$

(3 × 3) (9)

5.2



(7)

## 5.3 Step 1

- Set derivative time to zero.✓
- Start with a wide proportional band and narrow it gradually step by step✓ while observing the behaviour following the set point changes until the desired stability is obtained, i.e. a damping ratio of 0,25.✓

## Step 2

- Allowing the proportional band to remain at this setting,✓ increase the derivative time in small steps while creating set point load changes until the cycle behaviour begins to increase,✓ then slightly reduce the derivative time.✓

(6)  
[22]**QUESTION 6**

6.1 The purpose of the feedwater control system is to maintain the proper amount of water in the drum✓ during all load conditions.✓

(2)


- 6.2
- The transmitter should be an absolute pressure type
  - The pressure transmitter should be mounted above the taps
  - The transmitter should have slight bleed of air
  - or gas into the line to keep it free of condensate.

(4)

- 6.3
- Pressure in the column
  - Flow rate of the incoming feed
  - Flow rate of the bottom product or residue
  - Flow rate of the top product or distillate
  - Column-feed temperature cascaded onto the steam flow to the preheater
  - Top temperature control cascaded onto the reflux flow
  - Temperature cascaded onto the steam flow control to the reboiler
  - Heat removed from the system

(8)

6.4

(9)  
[23]**QUESTION 7**

- 7.1
- What level of energy is incapable of igniting a hazardous atmosphere mixture?
  - What is a specific atmospheric mixture?
  - What are normal and abnormal conditions?
- (3)
- 7.2
- It prevents the output signal in the field from releasing sufficient electrical or thermal energy under normal or abnormal conditions to ignite a specific hazardous atmospheric mixture.
- OR**
- It prevents high voltage and currents to flow through the hazardous area.
- (3)
- 7.3
- Series protective elements
  - Transformer construction
  - Shunt protective elements
  - Zener barrier
- (4)  
[10]

**TOTAL SECTION B: 80**  
**GRAND TOTAL: 100**